




ASSEMBLY AND INSTALLATION

OF 5/16" O.D. NYLON TUBE FITTING



1. Cut the tubing with a razor blade or very sharp knife, leaving the cutoff end as square as possible.
2. Slip the nut over the tubing end—(nut should slide freely)
3. Push the lock over the end of the tubing and move it back at least one insert length from the end. The lock may slide on freely or require a light press or screw-on action (The lock has a left hand thread.)
4. Install the seal over the end of the tubing and against the lock—**MAKE SURE IT IS NOT TWISTED.**